

<b>Make/Bilmerke:</b> Hyundai Sonata/i40 2009-	Location: Right side storage bin Plassering: Til høyre for oppbevaringsrom	Tape: no
		Date/Dato: 04.06.2008

English

Step 1: Unclip the trim surrounding the gear shifter. Unscrew the 2 Phillips screws as shown in photo.

Step 2: Pull the moulding out at lower base and unclip and set aside so you can access the screws behind.

Step 3: Install the DashMount on the Phillips-screw as shown in the photo.

Step 4: Reinstall the trim in reversed order.

Norsk

Steg 1: Trekk opp panelet rundt girspaken i midtkonsollen. Skru så ut de 2 skruene som kommer til syne og som vist på bilde.

Steg 2: Trekk så ut panelrammen ved foten og ta den så vekk slik at du kommer til skruene på høyre side.

Steg 3: Monter DashMounten på Phillips-skruen du finner på siden av oppbevaringsboksen, slik som vist på bildet.

Steg 4: Sett paneler tilbake på plass igjen.



Important! Clean tape area when tape is required for maximum stability. Press hard on tape for 5-10 seconds.

NB: Rengjør i området hvor tapen skal feste for best mulig stabilitet. Press godt inn i 5-10 sek. slik at tapen fester.

MTU Distribution AS may not be held liable for any damage to a vehicle connected to the installation.