

Make/Bilmerke: Nissan Interstar 2010- Opel Movano 2010- Renault Master 2010-	Location: Right side radio Plassering: Høyre side radio	Tape: no
		Date/Dato: 2010.06.29

English

Step 1: Pull out clipboard or storage bin if so equipped in the top of the dashboard.

Step 2: Remove the 2 screws that appears and pull the unit out some 4-5 cm.

Step 3: Install the DashMount behind the unit on right side and push the unit back into position making sure the screw hole aligns. Refit the screws as shown in photo.



Norsk

Steg 1: Trekk ut papir tavlen, eventuelt oppbevaringshyllen øverst i dashbordet.

Steg 2: Skru ut 2 skruer som kommer tilsyne og trekk enheten ut 4-5cm.

Steg 3: Plasser DashMounten bak enheten på høyre side, dytt enheten tilbake på plass og skru tilbake skruene.



Important! Clean tape area when tape is required for maximum stability. Press hard on tape for 5-10 seconds.

NB: Rengjør i området hvor tapen skal feste for best mulig stabilitet. Press godt inn i 5-10 sek. slik at tapen fester.

TeleD AS may not be held liable for any damage to a vehicle connected to the installation.

