

**Toyota Picnic
1997-
70566**



This Dash Mount is designed for:

Toyota Picnic..... 1997-

Location:

Right side of the center console

Tools Required:

Screwdriver + flat bending tool



Monteringsanvisning

Steg 1: Under lokket for oppbevaringsrommet i midt-konsolet finner du 2 skruer som skrues ut. Deretter kan du vippe ut hele midt-konsolet ved å starte ifra toppen. På høyre siden av radioen finnes 3 skruer som må løsnes og den midterste må helt ut. Trekk så stårammen litt ut.

Steg 2: Plasser Dash Mountens arm under den midterste skruen. Sentrer styretappen på det øverste hullet. Skru godt til og plasser panelet på plass igjen.



Mounting Instruction

Step 1: Underneath the centre storage lid you will find 2 screws that must be removed. Then flip out the complete pane assembly by pulling straight out from the top and downwards. At the right side of the radio there are 3 screws that you must loosen and the centre one must be removed.

Step 2: Locate the Dash Mount arm behind the steel frame and centre it on to the location tab. Replace screw and tighten well. Put the panels back into position.



Correct direction of the rose pattern.



Do not use force when working with plastic components. Use extreme care not to scratch the interior of the vehicle. MTU may not be held liable for any damage to a vehicle connected to the installation.



Dato / Date: 31.05.99